

**Thanks for Ordering
The Kawasaki Vulcan 800 V-Shield Adapter Kit**



READ THIS BEFORE UNPACKING YOUR KIT!

This instruction booklet contains the basic steps for installing the V-Shield mounting adapter on Kawasaki Vulcan 400A/B and 800A/B motorcycles. If you have any questions concerning installation of your new Scootworks accessory, please contact us via e-mail at support@scootworks.com. This will ensure you receive the most prompt and accurate reply.

Copyright 2000-2005 Scootworks, Inc. All Rights Reserved.

All graphics, and descriptions in this installation instruction booklet are intended for personal use only. Any reproduction, publishing or distribution of any materials in this booklet is strictly prohibited without the expressed written consent of Scootworks, Inc.

Instructions for Installing the Scootworks V-Shield Adapter on Vulcan 400 and 800 Motorcycles

Tools Needed:

- 14mm open-end wrench
- Torque Wrench
- 14mm Socket

BEGIN INSTALLATION

1. Remove the 14mm bolt in the center of the intersection of the cylinders. Install the bracket as seen in the photo below, and torque to 29 ft/lbs.



2. Install the V-Shield to the upper hole in the bracket as per the instructions in the V-Shield. You're done!