

**Thanks for Ordering
The Tour Pack Backrest
from**



READ THIS BEFORE UNPACKING YOUR KIT!

This instruction booklet contains detailed steps for installing the Scootworks Tour Pack Backrest. If you have any questions concerning the installation of your Scootworks Tour Pack Backrest, please contact us via e-mail at support@scootworks.com. This will ensure you receive the most prompt and accurate reply.

Rev 1.1; 3/29/2003

Copyright ©1998-2003 Scootworks, Inc. All Rights Reserved.

All graphics, and descriptions in this installation instruction booklet are intended for personal use only. Any reproduction, publishing or distribution of any materials in this booklet is strictly prohibited without the expressed written consent of Scootworks, Inc.

Instructions for Installation of the Scootworks Tour Pack Backrest

Tools Needed:

- Sharp Razor knife or scissors
- Felt tip pen
- Masking tape
- 12" piece of string
- 1/16" and 3/8" drill bits
- Electric drill
- Wrench to fit the hex nuts supplied on the backrest

Installation of the Tour Pack Backrest is very straight forward, but Scootworks wanted to assist you as much as possible with the disassembly process, and developed this instruction manual. If there are any steps you feel need improvement in instructions, please email support@scootworks.com and specify the area you are having trouble with.

UNPACKING!

The shipping container and contents must be inspected by the purchaser for damage to goods immediately upon receipt of goods, and a claim must be filed with the carrier if damage is discovered. The purchaser must contact Scootworks within 24 hours from receipt of damaged goods to file a claim, and for further instructions. Your Scootworks Rear Shock Spring Compressor will come packed with these printed instructions.

Unpack the backrest and study its design carefully. The paper mounting template will require some trimming and a test fit on the backrest prior to installing. Cut off the shaded areas of the template to follow the contour of the trunk.

Once you have trimmed and cut out the template, make a small hole where the mounting studs are shown on the template. Since the backrest is hand made, slight variances exist from unit to unit. Carefully place the printed side of the template onto the four (4) mounting studs on the rear of the backrest. If you need to make a slight adjustment to the hole location on the template, do so now.

Place a strip of masking tape across the top of the trunk. Measure across the top of the trunk, and mark the center point on the masking tape. Attach a piece of masking tape along the black rubber trim on the front of the trunk, and locate its center point as well. Attach a piece of string to the center marks from the 2 strips of tape, forming a vertical center line. Using this vertical centerline, place the 2 alignment marks on the template (for the top and bottom centerline) over the string. Slide the lower edge of the template down against the top edge of the rubber strip. Place masking tape at the four corners of the template to hold it in place while marking the drill points. The horizontal line on the

template should be at the beginning edge of the curve on the top of the trunk. Mark the four holes with a felt tip pen and remove the template. Carefully drill four 1/16" pilot holes on the box. If you purchased the trunk with the backrest, the pilot holes may be present. Redrill the pilot holes with a 3/8" drill. Be careful to drill slowly and a smooth hole will be present. Remove the tape from the trunk and prepare to mount the backrest.

Installing the backrest requires some patience in positioning to avoid scratching the trunk's finish. Carefully position the mounting studs on the main part of the backrest at the holes in the front. Tilt the backrest so the mounting studs on the top will not touch the finish. While pushing the backrest mounting studs into the trunk flex the top of the backrest up and away from the trunk. This will allow the front-mounting studs to slide into the trunk leaving the top-mounting studs in position to slide in from the top. Once the backrest is on the lid, open the trunk and attach the mounting washers and nuts. You should then tighten until snug. Do not over tighten.

Your Scootworks backrest is made from high quality material used in the automotive industry and will provide you with many years of good service. It has been designed to give firm and comfortable full back support to your passenger.

Any questions? Contact Scootworks at support@scootworks.com, or (919)554-9227.