

**Chin Spoiler Installation Instructions for the
Kawasaki 1500 Classic, Kawasaki 1500/1600
Mean Streak, & 1600 Suzuki Marauder**

1- Remove the horn. Attach the horn wiring extension to the horn wires. Reinstall the horn on the studs in the inside lower section of the cowling using two of the nuts. Plug the extension onto the horn.

2- Look under the radiator, you'll notice two pre-drilled holes in the lower radiator bracket that match up with the remaining two studs in the lower spoiler section. Place the lower studs through those holes, and use the remaining two nuts and two of the washers to secure the lower section of the spoiler.

3- Raise the top of the spoiler towards the tank and you'll find two holes predrilled in the webbing of the frame immediately in front of the gas tank (one hole on either side). There are two nuts formed into the upper "wings" of the spoiler that match up with those holes (one on each side). Gently spread the spoiler open a bit, and slip it into place. Use the two allen bolts and remaining two washers supplied to secure the top portion of the spoiler in this way.