

Items Supplied >

- 2 – 6mm X 15mm Flange Bolts
- 2 – ¼(20) X ¾ S/S Button Head bolts
- 1 – Push On Terminal
- 1 – Black Power Wire
- 1 – Blue Quick Splice Connector
- 2 – Aluminum Turn Signal Adaptors

Application(s) >

KAWASAKI VN1600A 03

Instruction Manual >

04-0461

Page 1 of 1

Read your installation instructions completely before beginning. This light bar can be installed in just a few minutes using common tools. It is recommended however, that a qualified mechanic or technician install this product.

1. Your Boulevard Light Bar comes with everything you need to mount and wire it to your motorcycle. After unpacking the light bar, you will need to turn the spot lights around 180 degrees. They are facing backwards for packaging purposes only.
2. Remove the head light from the housing to access turn signal wires. Unplug both front turn signals and remove the mount bar they are attached to from under the lower triple clamp.
3. Remove the turn signals from the stock mount bar. Remove the o-rings from the stock mount bar and place them onto the groove on the supplied aluminum turn signal adaptors. Place stock turn signals onto adaptors by pulling the wires through the hole cut into the adaptors. Secure turn signals by installing the stock screws.
4. Install both turn signals on to the Cobra light bar using the supplied ¼(20) x ¾ button head bolts. The turn signals go on the bottom of the light bar with the button head bolts on top.
5. Install the light bar under the lower triple clamp on the same holes the turn signal mount bar was removed from using the supplied 6mm X 15mm bolts.
6. Align the turn signals and spotlights, check to make sure all the bolts are snug.
7. Twist the ends of the two spotlight wires together and insert in to the supplied push on connector and crimp with a crimping tool. Connect push on terminal to one of the poles on the light bar switch, it does not matter which one.
8. Feed the supplied black power wire from the other pole on your switch through the back of the headlight housing and connect it to the red/blue front running light wire using the supplied blue quick splice.
9. Plug your turn signals back into the original location and reinstall headlight.

*** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**